

FLYWHEEL POWER TAKE-OFFS

FLYWHEEL POWER TAKE-OFFS

STEEL

Precision drilled and tapped to receive 1310 or 1350 drive lines. Bolts to the flywheel or flexplate, bolt pack included. To determine drive line series, measure the registration (see photo at right).

1310 Series Male Pilot - 2-3/8"

1350 Series Male Pilot - 2-3/4"

1310 DRIVE LINE SERIES

Drive Line	Item No.
Chevy - Automatic	793-E
Chevy - Standard	793-F
Chrysler 6 Bolt	793-G
Chrysler 8 Bolt	793-H
Ford - 272-312	793-I
Ford - 289-351	793-J
Ford - 331-460	793-K
65 Olds (425 c.i.)	793-L
66-81 Olds (350-455 c.i.)	793-M*
59-64 Pontiac	793-N
65-88 Pontiac	793-O
Chevy (87 & newer) -Auto	793-P
Chevy (87 & newer) - Std	793-Q
Chevy (81-86 V-6) - Auto	793-R
Chevy (81-86 V-6) - Std	793-S
Chevy LS-1 (PG or Std)	793-T*

*SPECIFY IF STANDARD OR AUTOMATIC



1350 DRIVE LINE SERIES

Drive Line	Item No.
Buick Automatic - 55-56	796-A
Buick Automatic - 57-65	796-B
Buick Automatic - 66-88	796-C
Cad/Oldsmobile - 49-64	796-D
Chevy - Automatic	796-E
Chevy - Standard	796-F
Chrysler 6 Bolt	796-G
Chrysler 8 Bolt	796-H
Ford 2.3 Liter	796-I
Ford - 289-351	796-J
Ford - 331-460	796-K
Olds (350-455c.i.)*66-81	796-M*
Pontiac - 59-64	796-N
Pontiac - 65-88	796-O
Chevy (87 & newer) -Auto	796-P
Chevy (87 & newer) - Std	796-Q
Chevy LS-1 (PG or Std)	796-T*

*SPECIFY IF STANDARD OR AUTOMATIC

CHEVROLET 1/2" SPACERS FOR AUTOMATIC FLYWHEEL FOR REVERSE ENTRY STARTERS

	Item No.		Item No.
Big Block Chevrolet	793	Chevrolet (87)	796

BORG WARNER POWER TAKE-OFF

STEEL

Made exclusively to fit Borg Warner Velvet Drive transmission for model 71 and 72 gears. Flange adapter is drilled and tapped to receive the 1310 or 1350 drive line series.

Drive Line Series	Item No.
1310 for 71 Gear	794
1350 for 71 Gear	797
1310 for 72 Gear	795
1350 for 72 Gear	798

